



**Integrated Audio  
and Visual alarm  
that alerts when open**

**NC16C12-SE1-AVD**

## MEDIUM NARCOTICS CABINET

with Electronic Pushbutton Locking Outer Door

### Construction:

- Heavy duty 20 gauge steel

### Features:

- Cabinet has integrated Audio and Visual alarm to alert personnel when open
- Battery-powered using standard 9 volt; battery in quick-change holder
- Does not need to be hard-wired to electrical power - can be mounted anywhere
- Single outer door construction
- Basic electronic pushbutton lock with key lock override
- Factory set user and supervisor code
- Cabinet may be programmed in the field
- Full length stainless steel pinned door hinges prevent pin removal
- One adjustable and/or removable shelf with the choice of five locations
- Predrilled holes in the back for mounting on a wall, cabinet or other solid surface (wall mounting hardware included)
- Narcotics cabinet is delivered ready to use
- Durable heat sealed powder coat finish

*This cabinet is compliant with DEA guidelines for the secure storage of Schedule III, IV, and V controlled substances when a separate outer door is also used, such as inside a drawer or cabinet within a locked office or in a locked refrigerator/freezer within a locked office. Because this narcotics cabinet does not have both an inner and outer door, it is not recommended for the storage of Schedule I and II controlled substances unless additional criteria is met. Please consult current DEA guidelines for details.*



Shown in gloss beige (default color). More than 20 additional colors are available.



Engineered & Manufactured in the U.S.

Keys with black tips must be used in locks with black ring. Putting the wrong key in a lock will disable the lock and require the lock to be replaced.



One lock and key set includes a black identifier

Harloff offers many different narcotic cabinets to help you keep both your controlled substances and your business secure including wood look cabinets, slim profile boxes and cabinets with audio/visual alarms.

#### Assembled Cart Dimensions:

- 16" H x 12" W x 8" D (41 cm H x 30.5 cm W x 20.4 cm D)
- Cabinet weight: 15 lbs (6.8 kg)
- Approximate shipping weight: 17 lbs (7.7 kg)
- Approximate shipping dims: 18" H x 16" W x 12" D (45.7 cm H x 40.6 cm x 30.5 cm D)

**Warranty:** 12-Year Manufacturer's Warranty on shipments to US and Canada, 5-Year Manufacturer's Warranty on all other International shipments. 1-Year Limited Warranty on any bought-out parts

View similar products online at

<https://www.harloff.com/product-category/narcotics-medicine-cabinets/>

Toll Free: (800) 433-4064 • [medicalsales@harloff.com](mailto:medicalsales@harloff.com)  
[www.harloff.com](http://www.harloff.com) • Ph: (719) 637-0300

**HARLOFF**  
INNOVATING STORAGE FOR CARE