



# WV2760-DG

## WALL MOUNT MEDICATION CABINET

Vinyl Coated Aluminum Single Door w/Single Lock

### Features:

- Heat sealed powder coat steel cabinet body
- Key lock with two keys
- Multiple cabinets may be keyed differently or keyed alike – must be specified on order
- In-room medication cabinet for 1 - 2 residents
- Drop down shelf
- Capacity of 40 punch cards / liquid storage
- Matching cabinet wrap and vinyl trim set included
- Door is vinyl coated aluminum with a rich wood appearance
- One hand open and close slam lock
- Cabinet can swing open to the left (WV2760L)
- Stainless steel pinned door hinges prevent pin removal
- Predrilled holes and hardware included for either exterior wall mounting or in wall mounting between wooden studs with 16" centers
- Cabinet is delivered ready to use
- Twelve year warranty against manufacturer defect
- Durable hard-baked powder coat finish paint on cabinet – Color is gloss beige



Engineered & Manufactured in the U.S.



**Overall Cart Dimensions:**

- 23" H x 14.625" W x 6.75" D (58.4 cm H x 37.1 cm W x 17.1 cm D)
- Net weight: 20 lbs (9 kg)
- Approximate shipping weight: 25 lbs (11.3 kg)



Driftwood Gray (DG)

### Colors:

Shown in Driftwood Gray. Harloff offers two standard vinyl color options, plus additional special order vinyl color options with a minimum cabinet purchase and extended lead time.

### Cabinet Options:

Convert one row of your cabinet into a locked narcotics storage box (WV2760NARC).



Upgrade to an electronic keypad lock (WV2760E) with multiple user and supervisor codes. Can be programmed in the field.



Add the look of wood to functional storage for an attractive in-room storage solution. Purposely designed to meet industry standards for security and function. Cabinet is designed for in wall stud mounting. Slam lock ensures security with one hand open and closing. Drop down shelf included to provide area for medication preparation.



View similar products online at

<https://www.harloff.com/product-category/medication-furniture-carts-cabinets/>

Toll Free: (800) 433-4064 • [medicalsales@harloff.com](mailto:medicalsales@harloff.com)  
www.harloff.com • Ph: (719) 637-0300